

SLAVE AMPLIFIER PARTS LIST

MASTER AMP MK6	MK6 SLAVE	MK8 SLAVE
INSTRUCTIONS	√	√
VOLUME CONTROL	√	√
POWER SPLITTER HARNESS	2 x MALE 1 x FEMALE 12 - WAY	2 x MALE 1 x FEMALE 12 - WAY
SPEAKER MATCHING PAD	√	√
4 WAY HARNESS	4 - WAY STOCKO AT ONE END √	4 - WAY STOCKO AT BOTH ENDS √
2 x 2.5A FUSES 2 x 6.3A FUSES (20 mm)	√	√
4 x GREY SPACERS	√	√
4 x MOUNTING PILLARS		
FAN STRIP		
SIGNAL LEAD	3 - PIN DIN AT ONE END ONLY √	3 - PIN DIN AT ONE END ONLY √
4 x SCREWS	4 x (M4x ⁵ / ₈) POZIPAN √	4 x (M4x ⁵ / ₈) POZIPAN √

MASTER AMP MK8	MK6 SLAVE	MK8 SLAVE
INSTRUCTIONS	√	√
VOLUME CONTROL	√	√
POWER SPLITTER HARNESS	2 x MALE 1 x FEMALE 12 - WAY	2 x MALE 1 x FEMALE 12 - WAY
SPEAKER MATCHING PAD	√	√
4 WAY HARNESS	4 - WAY STOCKO AT ONE END √	4 - WAY STOCKO AT BOTH ENDS √
2 x 2.5A FUSES 2 x 6.3A FUSES (20 mm)	√	√
4 x GREY SPACERS	√	√
4 x MOUNTING PILLARS		
FAN STRIP		
SIGNAL LEAD	3 - PIN DIN AT ONE END ONLY √	3 - PIN DIN AT ONE END ONLY √
4 x SCREWS	4 x (M4x ⁵ / ₈) POZIPAN √	4 x (M4x ⁵ / ₈) POZIPAN √

MASTER AMP MK7	MK7/8 SLAVE	MK7/8 SLAVE (KIOSK)	MK7/8 SLAVE (SURFER)
INSTRUCTIONS	√	√	√
VOLUME CONTROL	√	√	√
POWER SPLITTER HARNESS	2 x MALE 1 x FEMALE 6 - WAY	2 x MALE 1 x FEMALE 6 - WAY	
SPEAKER MATCHING PAD	√	LONG LEAD REQUIRED √	√
4 WAY HARNESS	4 - WAY STOCKO AT BOTH ENDS √	4 - WAY STOCKO AT BOTH ENDS √	4 - WAY STOCKO AT BOTH ENDS √
2 x 6.3A FUSES	√	√	√
4 x GREY SPACERS			
4 x MOUNTING PILLARS	√	√	√
FAN STRIP	√	√	√
SIGNAL LEAD	5 - PIN STOCKO TO 3- PIN √	5 - PIN STOCKO TO 3- PIN √	5 - PIN STOCKO TO 3- PIN √
4 x SCREWS			